


# Profi-Mikrowelle RCS 511 DSE



**BEFORE SERVICING** Discharge the high voltage capacitor by shorting the negative high voltage terminal of it to chassis ground